

## IMPORTANT

### Installation of Bilstein® Aftermarket Shock Absorbers on pre-1989 Chevrolet P30 chassis (part # B46-1404, B46-1501, B46-1587)

The upper OEM shock mount on pre-1989 Chevrolet P30 chassis is not sufficiently strong to support the damping loads produced by aftermarket shock absorbers. Those mounts must be reinforced to prevent fatigue failure.

The recommended reinforcement is to weld the existing OEM shock mount stem solidly to the formed frame bracket (see illustration below). **Before welding, ensure that all wires, cables, lines, and other flammable materials are properly shielded and protected, and that the area under the motorhome is well ventilated.**

Bilstein assumes no responsibility for reinforcement or durability of the OEM shock mounts; nor does Bilstein's Limited Warranty apply to these items or to damage resulting from failure of the OEM mounts.

(Owners of 1989 and newer chassis please disregard this notice.)

